

Endbac Sanit tablets

Chlorine Tablets for Food Surfaces and Salad Washing

Description

• Chlorine based sanitising tablets for food contact surfaces and salad washing.

Key properties

- Chlorine based.
- Fast dissolving.

Benefits

• Effective sanitising of all surfaces in kitchens and food preparation environments and for salad washing.

Use instructions

For general use. Dilute 1 tablet with 5 litres of water. Apply with a mop, sponge, cloth or spray bottle. Allow 5 minutes contact time before cleaning and rinsing with fresh water.

For heavy duty cleaning. Dilute 2 tablets with 5 litres of water. Apply with a mop, sponge, cloth or spray bottle. Allow 5 minutes contact time before cleaning and rinsing with fresh water

For salad/vegetable washing : Dilute 1 tablet in 5lts of cold water, Ensure tablet is fully dissolved. Remove gross soiling before adding salad/vegetables. Allow 5 minutes contact time, then remove from the solution and rinse thoroughly in potable water.

Typical Use	Tablet Use Rate	ppm av	vailable Chlorine
Soiled Mops	1per 3 Its water 200		
Soiled Cloths	1per 6 Its water 100		100
Salad Wash			
(Immediate Use)	1per 10lts water		60
Salad Wash			
(Delayed Use)	1per 5lts v	vater	120
Food Surface / Kitchens	1per 5lts v	vater	120
Technical data			

Description:	White tablets		
pH:	6.0-8.0		

The above data is typical of normal production and should not be taken as a specification.

Endbac Sanit tablets

Safe handling and storage information

- Avoid contact with skin and eyes. Rinse and dry hands after use, for prolonged contact protection of the hands may be necessary. Do not mix with any other chemicals other than as advised by your Diversey representative.
- Store upright in original closed containers in a cool place.

Full guidance on the handling and disposal of this product is provided in a separate Material Safety Data Sheet.

Microbiological data

• Conforms to EN1276

Available pack sizes

• 6 x 230 Tablets

Diversey Ltd Weston Favell Centre Northampton NN3 8PD Tel. 0800 525 525 www.diversey.com P91616GBEN-02